



Manufactured by:
Backyard Discovery
3305 Airport Drive, Pittsburg, KS 66762
800-856-4445

Basepoint Business Centre: Rivermead Drive, Westlea, Swindon SN5 7EX Phone: 0800-118-2476
J.P. Coenstraat 7, The Bridge, The Hague, 2595 WP, Netherlands Phone: 08005678990


FUSION FLAME 2 OUTDOOR KITCHEN

MODEL #: 2507036



WARNING

Cancer and Reproductive Harm
www.P65Warnings.ca.gov



Please visit www.backyarddiscovery.com
For the most up to date assembly manual, to register your product, or to order
replacement parts Para obtener instrucciones en español, visite
www.backyarddiscovery.com



EASY STEP-BY-STEP
3D INTERACTIVE INSTRUCTIONS
DOWNLOAD THE FREE APP




OWNER'S MANUAL - BASIC SETUP DIMENSIONS & ASSEMBLY NOTES

It is critically important that you start with square and level footings or concrete pad to attach your structure.


- Pay close attention to the items needed for each step. Make sure you are using the correct hardware for each step. Using incorrect hardware may result in improper assembly
- Remember to double check for underground utilities and overhead electrical lines

Post mounts are provided with your structure which allows you to permanently install your structure to a pre-existing or new wood or concrete surface. See Anchor Instructions for further details and recommendations.

- The hardware to attach the post mounts to the structure is included.
- The hardware to mount the structure permanently to a concrete surface is included.
- The hardware to mount the structure permanently to a wood deck is NOT included and will need to be purchased separately. You must ensure there is ample structural support under the deck before permanently attaching.





OWNER'S MANUAL - ANCHORING LAYOUT




NOTE: DIMENSIONS ARE TO ANCHOR PLATES MOUNTED TO POSTS EXCEPT WHERE NOTED.

OWNER'S MANUAL - UTILITY LAYOUT




OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)




S1 SIDE PANEL ASSEMBLY - A4M05448
(x1) 33 3/4"x25"x1 3/8" (35x635.0x857)



S2 SIDE PANEL ASSEMBLY - A4M05449
(x1) 33 3/4"x25"x1 3/8" (35x635x857)




S3 SIDE PANEL ASSEMBLY M - A4M05485
(x1) 24"x22 5/8"x1 3/8" (35x574x610)




S4 SIDE PANEL ASSEMBLY - A4M05458
(x1) 33 3/4"x25"x2 11/16" (68x635x857)




S5 SIDE PANEL ASSEMBLY - A4M05460
(x1) 33 3/4"x25"x1 3/8" (35x635.0x857)



S6 SIDE PANEL ASSEMBLY M - A4M05483
(x1) 26 3/16"x24"x1 3/8" (35x609x665)




S7 SIDE PANEL ASSEMBLY - A4M05475
(x1) 33 3/4"x25"x1 3/8" (35x635x857)




S8 SIDE PANEL ASSEMBLY - A4M05476
(x1) 33 3/4"x25"x1 3/8" (35x635x857)

OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)




F1 FLOOR PANEL ASSEMBLY - A4M05447
(x1) 28 5/8"x25"x1 3/4" (45x635x727)




F3 FLOOR PANEL ASSEMBLY - A4M05457
(x1) 18 1/8"x25"x1 3/4" (45x635x460)




F4 FLOOR PANEL ASSEMBLY - A4M05466
(x1) 31 7/16"x25"x1 3/4" (45x635x798)




F5 FLOOR PANEL ASSEMBLY - A4M05473
(x1) 28 5/8"x25"x1 3/4" (45x635x727)




F8 FLOOR PANEL ASSEMBLY - A4M05758
(x1) 38 1/4"x25"x1 3/4" (45x635x971)




T1 TABLETOP PANEL ASSEMBLY - A4M05451
(x1) 28 5/8"x25 5/16"x1 5/8" (41x643x727)




T2 TABLETOP PANEL ASSEMBLY - A4M05455
(x1) 38 1/4"x25"x1 9/16" (40x635x971)



T3 TABLETOP PANEL ASSEMBLY - A4M05463
(x1) 25 5/16"x18 1/8"x1 5/8" (41x460x643)




T4 TABLETOP PANEL ASSEMBLY - A4M05470
(x1) 31 7/16"x25"x1 9/16" (40x635x798)




T5 TABLETOP PANEL ASSEMBLY - A4M05479
(x1) 28 5/8"x25 5/16"x1 5/8" (41x643x727)

OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)




L1 SHELF - A4M05486
(x1) 24"x18 3/8"x1" (25x467x610)



L2 SHELF - A4M05484
(x1) 24"x14 13/16"x1" (25x376x610)




G1 BACK PANEL ASSEMBLY - A4M05452
(x1) 33 3/4"x25 3/4"x1 3/16" (30x655x857)



G2 BACK PANEL ASSEMBLY - A4M05456
(x1) 38 1/4"x22 5/8"x1 3/16" (30x574x971)




G3 BACK PANEL - A4M05461
(x1) 1 1/6"x15 1/4"x33 3/4" (30x388x857)




G4 BACK PANEL ASSEMBLY - A4M05468
(x1) 31 7/16"x26 3/16"x1 3/16" (30x666x798)



G5 BACK PANEL ASSEMBLY - A4M05477
(x1) 33 3/4"x25 13/16"x1 3/16" (30x655x857)



G11 VENTILATION PANEL - A4M03056
(x1) 1 5/16"x11 3/16"x38 3/16" (33x284x970)




O8 VENTILATION PANEL - A4M03078
(x1) 1 3/16"x3 3/4"x31 7/16" (30x95x798)

OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)




D1 DOOR ASSEMBLY - A4M05487
(x1) 22 3/8"x18 7/8"x7/8" (22x480x568)



D2 DOOR ASSEMBLY - A4M05488
(x1) 22 3/8"x18 7/8"x7/8" (22x480x568)




D3 DRAWER PANEL ASSEMBLY - A4M05464
(x1) 22 7/16"x15 1/8"x7/8" (22x384x569)




D4 DRAWER PANEL ASSEMBLY - A4M05465
(x1) 15 1/8"x10 15/16"x7/8" (22x278x384)




D5 DOOR ASSEMBLY - A4M05472
(x1) 22 3/8"x15 1/2"x7/8" (22x393.5x569)



D6 DOOR ASSEMBLY - A4M05471
(x1) 22 3/8"x15 1/2"x7/8" (22x393.5x569)



D7 DRAWER BODY ASSEMBLY - A4M05489
(x1) 22 9/16"x13 1/4"x7 1/8" (181x337x573)




D8 DOOR ASSEMBLY - A4M05480
(x1) 33 1/2"x12 11/16"x7/8" (22x324.1x851)




D9 DOOR ASSEMBLY - A4M05481
(x1) 33 1/2"x12 11/16"x7/8" (22x322x851)

OWNER'S MANUAL - PARTS IDENTIFICATION

METAL COMPONENTS (NOT TO SCALE)



H4 BEAM - A4M05469
(x1) 31 7/16"x3 9/16"x1 3/8" (35x90x798)




H3 TRASH CAN BRACKET ASSEMBLY - A4M05490
(x1) 18"x13 5/16"x1 3/8" (35x337x458)



A01 BRACKET - A4M02018
(x6) 1"x1 5/16"x5 1/16" (25x33.2x128)




A2 MAGNET BRACKET - A4M03026
(x6) 1"x1 1/4"x3 1/8" (25x31x80)




A4 RESTRICTIVE BRACKET - A4M06228
(x1) 2 3/4"x7/8"x7/16"x7/16" (11.5x21.5x70)




A5 SHELF BRACKET - A4M03141
(x4) 5/8"x7/8"x2 1/16" (16x22x53)



A6 ANGLED BRACKET - A4M03053
(x4) 1 3/8"x 1 15/16"x17 1/8" (35x50x435)




A7 BACK SHELF - A4M06229
(x4) 2 7/16"x7 15/16"x17 11/16" (61x201x450)




A9 HOSE BRACKET ASSEMBLY - A4M03060
(x2) 1 1/4"x1 7/16"x2 9/16"(31.5x36.5x65)



A11 TRIANGLE PANEL - A4M03086
(x2) 13/16"x13 3/4"x13 3/4" (20x350x350)




A13 GAS TANK HOLDER ASSEMBLY - A4M03047
(x2) 1 15/16"x12 7/8"x14 3/4" (49x327x374)




A16 SINK ASSEMBLY - A4M03143
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)

OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)




P01 FRONT POST ASSEMBLY - A4M05508
(x1) 4 3/4"x5 15/16"x89 1/2" (120x151x2274)




P02 FRONT POST ASSEMBLY - A4M05509
(x1) 4 3/4"x5 15/16"x89 1/2" (120x151x2274)




P03 BACK POST ASSEMBLY - A4M05510
(x1) 4 3/4"x5 15/16"x88 3/4" (120x151x2254)




P04 BACK POST ASSEMBLY - A4M05499
(x1) 4 3/4"x5 15/16"x88 3/4" (120x151x2254)



P05 BACK POST ASSEMBLY - A4M05507
(x1) 2 5/8"x7 7/8"x88 3/4" (66x200x2254)




P06 BACK POST ASSEMBLY - A4M05497
(x1) 2 5/8"x7 7/8"x88 3/4" (66x200x2254)



B01 SIDE BEAM - A4M02012
(x1) 36x5 1/4"x46 1/2" (36x134x1181)



B04 SIDE BEAM - A4M02019
(x1) 1 7/16"x5 1/4"x18 7/8" (36x134x480)




B05 SIDE BEAM - A4M02022
(x1) 1 7/16"x5 1/4"x46 1/2" (36x134x1181)




B11 SIDE BEAM - A4M02106
(x1) 1 7/16"x5 1/4"x18 7/8" (36x134x480)

OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)




B08 CORBEL - A4M02041
(x1) 1 7/16"x6 11/16"x11 1/8" (36x170x282)



B09 CORBEL - A4M02042
(x1) 1 7/16"x6 11/16"x11 1/8" (36x170x282)



B10 BACK WALL ASSEMBLY - A4M05491
(x4) 1 7/16"x22 11/16"x23 3/8" (36x576.5x594)



B02 BEAM ASSEMBLY - A4M05493
(x2) 1 7/16"x4 13/16"x77 3/8" (36x122x1965)



B03 BEAM ASSEMBLY - A4M05494
(x1) 1 7/16"x5 1/4"x78 13/16" (36x134x2003)




B07 BEAM ASSEMBLY - A4M05496
(x1) 1 7/16"x5 1/4"x78 13/16" (36x134x2003)



J1 SPLICE BRACKET - A4M02230
(x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)




J2 SPLICE BRACKET - A4M05761
(x1) 1 5/16"x4 11/16"x39 3/8" (33.2x119.2x1000)



R01 RAFTER - A4M02020
(x6) 3 1/8"x3 15/16"x45 1/16" (80x100x1144)

OWNER'S MANUAL - PARTS IDENTIFICATION

METAL COMPONENTS (NOT TO SCALE)



E01 PURLIN ASSEMBLY - A4M05502
(x2) 1 9/16"x8 7/8"x66 3/16" (40x45x1681.25)




E02 PURLIN ASSEMBLY - A4M05503
(x2) 1 9/16"x19 15/16"x88 1/2" (40x45x2248.3)



E03 PURLIN ASSEMBLY - A4M05495
(x2) 1 9/16"x1 3/4"x23 3/8" (40x45x594)




E04 PURLIN ASSEMBLY - A4M05501
(x1) 1 9/16"x1 3/4"x87 13/16" (40x45x2230)




3113 29GA STEEL SHEETING - A4M03113
(x8) 1/4"x18 7/8"x46 7/16" (7x480x1179)




5500 29GA STEEL SHEETING - A4M05500
(x1) 1/4"x13"x46 7/16" (7x330x1179)



5504 DRIP EDGE - A4M05504
(x2) 1 1/2"x3 5/16"x76 11/16"
(0.5x84x1948)




5505 DRIP EDGE - A4M05505
(x1) 3/16"x3 7/16"x78 1/4" (6x88x1987)



5506 DRIP EDGE - A4M05506(x1)
3/16"x3 7/16"x78 1/4" (6x88x1987)



3118 DRIP EDGE SPLICE - A4M03118
(x1) 1 11/16"x3 7/16"x3 15/16" (0.5x88x100)




3114 DRIP EDGE - A4M03114
(x2) 7/16"x3 1/8"x46 1/4" (11x79x1175)




3122 DRIP EDGE SPLICE
- A4M03122(x1)
3/16"x3 1/2"x3 15/16" (6x90x100)

OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)



9230132 OUTDOOR KITCHEN FRIDGE - LEFT OPEN
(x1)



A4M05760 HINGE ASSEMBLY
(x12)



A4M02290 MAGNETIC PAPER TOWEL HOLDER
(x1)



H1 HOLE COVER - A4M01352
(x8)



3151 GARDEN HOSE ADAPTER - A4M03151
(x1)



H2 WOOD GRAIN HOLE COVER
A4M02078(x28)




9205413 ELECTRICAL ENCLOSURE
(x1)

OWNER'S MANUAL - PARTS IDENTIFICATION

WOOD AND PLASTIC COMPONENTS (NOT TO SCALE)




CB1 W4L22000 CUTTING BOARD
(x1)



530 2-WAY SQUARE PLUG - A6P00530
(x2)




A6P00679 EVA TAPE
(x16)




A6P00796 SILICONE SEALANT
(x1)

OWNER'S MANUAL - PARTS IDENTIFICATION


HARDWARE COMPONENTS




H101202 | TORX PAN HEAD
(x268) | 1/4-20x3/4 ASSY




H101117 | SCREW WOODGRIP
(x54) | 10-16 x 3/4




H101116 | SCREW SELF TAPPING
(x16) | 1/4x1 BLK




H101132 | TORX SOCKET SCREW SHORT
(x18) | 1/4-20




H101103 | TORX SOCKET SCREW
(x46) | 1/4-20




H100147 | TORX BIT
(x1) | T-30




H101100 | MAGNETIC DRIVER
(x1) |




H100114 | TORX BIT
(x1) | T-30




H101292 | TORX PAN HEAD
(x8) | 1/4-20x13/32"




H101185 | PHILLIPS FLAT HEAD
(x72) | 8-32x.5




H101289 | PAN HEAD SCREW
(x42) | 8-32x1/2" SS




H100120 | CONCRETE ANCHOR
(x14) | 1/4"x2"




H100630 | WASHER FLAT
(x14) | 8x19 BLK



H101106 | SOCKET DRIVER
(x1) |



H101294 | HEX DRIVER
(x1) |



**H101114 | RIGHT ANGLE
DRILL ADAPTER**
(x1) |


PRE-ASSEMBLY STEP 1 - SORTING PARTS

It is critical for ease of assembly that you take the time to sort and organize the parts and hardware.

METAL PARTS:


- Organize metal parts by the three-digit, alpha-numeric number stamped on each part (ex. P01).
- If there are multiple parts with the same stamped number, stack those pieces together.
- Stamps can be found on the flat surface of the parts or on the end of the parts.
- Allow yourself plenty of room - the parts can take up a significant amount of space.

NOTE: CARTONS ARE NOT ORGANIZED BY PART OR STEP NUMBER.



HARDWARE PARTS:

- We recommend that you have a separate table to organize the hardware.
- Hardware bags are printed with a seven-digit, alpha-numeric part number.
- You can organize your hardware by part number or group by hardware type (e.g. bolts, nuts, etc.).
- During assembly you only need to reference the last four digits of the number.



PRE-ASSEMBLY STEP 2 - TOOLS REQUIRED



Cordless Drill or
Electric Drill




Drill Attachments:
Phillips Head



1/8", 3/16", 3/8" &
7/16" Drill Bits



Phillips Screw Driver




Open End Wrench
7/16"




3/8" Drive Ratchet, 1/2" &
7/16" STD Sockets 1/2" & 7/16"
Deep Sockets




Claw Hammer



Rubber Mallet -
Optional



Tape Measure



Square




Level 24"

PRE-ASSEMBLY STEP 3 - CHOOSE YOUR ASSEMBLY METHOD

There are several types of assembly instructions available to you.

1. Printed Assembly Manual included with your set
2. BILT APP - 3D interactive instructions
3. Combination of the Printed Manual and BILT APP (Note: Step numbers can differ between the two methods)



The graphic is a rectangular frame containing the BILT logo (a hexagon with a dot inside) and the word "BILT." with a registered trademark symbol. To the right is a large QR code. Below the logo is the text "Scan for easy 3D instructions" and "Download the BILT app before you begin". To the right of this text are two buttons: "Download on the App Store" and "GET IT ON Google Play". At the bottom is a smartphone displaying a 3D assembly instruction for a metal frame, with a "Hardware Needed" label, a page number "17", and navigation icons.

BILT.[®]

**Scan for easy
3D instructions**

Download the BILT app
before you begin


Download on the
App Store

GET IT ON
Google Play

Hardware Needed


17

STEP 1- CABINET ASSEMBLY



F1 FLOOR PANEL ASSEMBLY - A4M05447
(x1) 28 5/8"x25"x1 3/4" (45x635x727)

- POSITION FLOOR PANEL IN THE PROXIMITY OF WHERE YOUR COOKING STATION WILL BE.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.




STEP 2- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

S2 SIDE PANEL ASSEMBLY - A4M05449
 (x1) 33 3/4"X25"X1 3/8"(35x635x857)




STEP 3- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

S1 SIDE PANEL ASSEMBLY - A4M05448
 (x1) 33 3/4"x25"x1 3/8" (35x635.0x857)


**S1 LABEL INDICATES
 TOP BACK OF SIDE PANEL**



S1 (x1)
 SIDE PANEL ASSEMBLY




1202 (x2)
 TORX PAN HEAD
 1/4-20x3/4 ASSY



**PANEL HOLES
 WILL FIT AROUND
 THREADED INSERTS**


STEP 4- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 9 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

G1 BACK PANEL ASSEMBLY - A4M05452
 (x1) 33 3/4"x25 3/4"x1 3/16" (30x655x857)


**G1 LABEL INDICATES
TOP OF BACK PANEL**




**1202 (x9)
TORX PAN HEAD
1/4-20x3/4 ASSY**



**G1 (x1)
BACK PANEL ASSEMBLY**




STEP 5- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 9 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

T1 TABLETOP PANEL ASSEMBLY - A4M05451
 (x1) 28 5/8"x25 5/16"x1 5/8" (41x643x727)

- FLUSH BACK AND SIDES OF PANEL ASSEMBLY.
- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.
- **ALIGN THREADED INSERTS IN TABLETOP WITH SLOTS IN SIDE AND BACK PANELS.**
- **SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.**
- **DO NOT USE TABLETOP SURFACE AS A WORK BENCH.**




STEP 6- CABINET ASSEMBLY




F8 FLOOR PANEL ASSEMBLY - A4M05758
(x1) 38 1/4"x25"x1 3/4" (45x635x971)

- POSITION FLOOR PANEL AS SHOWN BELOW.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.




STEP 7- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

A6 ANGLED BRACKET - A4M03053
(x1) 1 3/8" x 1 15/16" x 17 1/8" (35x50x435)




STEP 8 - CABINET ASSEMBLY




F3 FLOOR PANEL ASSEMBLY - A4M05457
(x1) 18 1/8"x25"x1 3/4" (45x635x460)

- POSITION FLOOR PANEL AS SHOWN BELOW.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.




STEP 9- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

S4 SIDE PANEL ASSEMBLY - A4M05458
 (x1) 33 3/4"x25"x2 11/16" (68x635x857)



STEP 10- CABINET ASSEMBLY




A6 ANGLED BRACKET - A4M03053
(x1) 1 3/8" x 1 15/16" x 17 1/8" (35x50x435)

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


1202 (x4)
TORX PAN HEAD
1/4-20x3/4 ASSY

A6 (x1)
ANGLED BRACKET

**MAKE SURE FRONT
FACE OF FLOOR
PANELS ARE FLUSH**





STEP 11- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 9 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


G2 BACK PANEL ASSEMBLY - A4M05456
 (x1) 38 1/4"x22 5/8"x1 3/16" (30x574x971)

**G2 LABEL INDICATES
 TOP OF BACK PANEL**




**G2 (x1)
 BACK PANEL ASSEMBLY**

**1202 (x9)
 TORX PAN HEAD
 1/4-20x3/4 ASSY**




STEP 12- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

S3 SIDE PANEL ASSEMBLY M - A4M05485
(x1) 24"x22 5/8"x1 3/8" (35x574x610)





STEP 13- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 4 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |

A2 MAGNET BRACKET - A4M03026
 (x2) 1"x1 1/4"x3 1/8" (25x31x80)




STEP 14- CABINET ASSEMBLY




A5 SHELF BRACKET - A4M03141
(x2) 5/8"x7/8"x2 1/16" (16x22x53)

- ATTACH SHELF BRACKETS ON BOTH SIDES OF CENTER CABINET.





STEP 15- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 2 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |

L1 SHELF - A4M05486
(x1) 24"x18 3/8"x1" (25x467x610)




L1 LABEL INDICATES
TOP OF FRONT SHELF





1289 (x2)
PAN HEAD SCREW 8-32x1/2" SS

STEP 16- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

A9 HOSE BRACKET ASSEMBLY - A4M03060
(x1) 1 1/4"x1 7/16"x2 9/16"(31.5x36.5x65)




STEP 17- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 4 | H101292 | TORX PAN HEAD 1/4-20x13/32" |



A13 GAS TANK HOLDER ASSEMBLY - A4M03047
 (x1) 1 15/16"x12 7/8"x14 3/4" (49x327x374)




A13 (x1)
GAS TANK HOLDER ASSEMBLY

1292 (x4)
TORX PAN HEAD
1/4-20x13/32"

NOTE ORIENTATION
OF WING NUT
TOWARDS FRONT



STEP 18- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 6 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

T2 TABLETOP PANEL ASSEMBLY - A4M05455
 (x1) 38 1/4"x25"x1 9/16" (40x635x971)


FLUSH BACK AND SIDES OF PANEL ASSEMBLY.

- **ALIGN SLOTS IN TABLETOP WITH THREADED INSERTS IN SIDE AND BACK PANELS.**
- **SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.**
- **DO NOT USE TABLETOP SURFACE AS A WORK BENCH.**




STEP 19 - CABINET ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 4 | H101103 | TORX SOCKET SCREW 1/4-20 |




1103 (x4)
TORX SOCKET SCREW 1/4-20




**MAKE SURE FRONT
FACE OF TABLETOP
IS FLUSH WITH
UPRIGHT PANEL**

STEP 20- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

G11 VENTILATION PANEL - A4M03056
 (x1) 1 5/16"x11 3/16"x38 3/16" (33x284x970)



1202 (x4)
 TORX PAN HEAD
 1/4-20x3/4 ASSY

G11 (x1)
 VENTILATION PANEL



STEP 21- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

S5 SIDE PANEL ASSEMBLY - A4M05460
 (x1) 33 3/4"x25"x1 3/8" (35x635.0x857)


S5 LABEL INDICATES TOP OF BACK PANEL

PANEL HOLES WILL FIT AROUND THREADED INSERTS

**1202 (x2)
TORX PAN HEAD
1/4-20x3/4 ASSY**

FLUSH FRONT FACE OF SIDE PANEL WITH FLOOR PANEL

**S5 (x1)
SIDE PANEL ASSEMBLY**



STEP 22- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 8 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

G3 BACK PANEL - A4M05461
(x1) (30x388x857)


1202 (x8)
TORX PAN HEAD
1/4-20x3/4 ASSY

G3 LABEL INDICATES
TOP OF BACK PANEL

G3 (x1)
BACK PANEL



STEP 23- CABINET ASSEMBLY






| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 8 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


T3 TABLETOP PANEL ASSEMBLY - A4M05463
 (x1) 25 5/16"x18 1/8"x1 5/8" (41x460x643)

- FLUSH BACK AND SIDES OF PANEL ASSEMBLY.
- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.
- **ALIGN THREADED INSERTS IN TABLETOP WITH SLOTS IN SIDE AND BACK PANELS.**
- **SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.**
- **DO NOT USE TABLETOP SURFACE AS A WORK BENCH.**

T3 LABEL ON
 BOTTOM SIDE
 INDICATES BACK




STEP 24- CABINET ASSEMBLY




F4 FLOOR PANEL ASSEMBLY - A4M05466
(x1) 31 7/16"x25"x1 3/4" (45x635x798)

- POSITION FLOOR PANEL AS SHOWN BELOW.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.



STEP 25- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


A6 ANGLED BRACKET - A4M03053
(x1) 1 3/8"x 1 15/16"x17 1/8" (35x50x435)

1202 (x4)
TORX PAN HEAD 1/4-20x3/4 ASSY

**MAKE SURE FRONT
FACE OF FLOOR
PANELS ARE FLUSH**




STEP 26- CABINET ASSEMBLY




F5 FLOOR PANEL ASSEMBLY - A4M05473
(x1) 28 5/8"x25"x1 3/4" (45x635x727)

- POSITION FLOOR PANEL AS SHOWN BELOW.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.




STEP 27- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


S8 SIDE PANEL ASSEMBLY - A4M05476
 (x1) 33 3/4"x25"x1 3/8" (35x635x857)

S8 LABEL
 INDICATES
 TOP OF
 BACK PANEL




1202 (x2)
 TORX PAN HEAD 1/4-20x3/4 ASSY

PANEL HOLES
 WILL FIT AROUND
 THREADED INSERTS




FLUSH FRONT
 FACE OF SIDE
 PANEL WITH
 FLOOR PANEL



S8 (x1)
 SIDE PANEL ASSEMBLY

STEP 28- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

A6 ANGLED BRACKET - A4M03053
(x1) 1 3/8" x 1 15/16" x 17 1/8" (35x50x435)


1202 (x4)
TORX PAN HEAD 1/4-20x3/4 ASSY

A6 (x1)
ANGLED BRACKET



**MAKE SURE FRONT
FACE OF FLOOR
PANELS ARE FLUSH**



STEP 29- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 9 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


G4 BACK PANEL ASSEMBLY - A4M05468
 (x1) 31 7/16"x26 3/16"x1 3/16" (30x666x798)

**G4 LABEL
 INDICATES
 TOP OF
 BACK PANEL**




**1202 (x9)
 TORX PAN HEAD 1/4-20x3/4 ASSY**

**G4 (x1)
 BACK PANEL ASSEMBLY**




STEP 30- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

S6 SIDE PANEL ASSEMBLY M - A4M05483
 (x1) 26 3/16"x24"x1 3/8" (35x609x665)




STEP 31- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 4 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |

A2 MAGNET BRACKET - A4M03026
(x2) 1"x1 1/4"x3 1/8" (25x31x80)




STEP 32- CABINET ASSEMBLY




A5 SHELF BRACKET - A4M03141
(x2) 5/8"x7/8"x2 1/16" (16x22x53)

- ATTACH SHELF BRACKETS ON BOTH SIDES OF CENTER CABINET.




STEP 33- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 2 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |

L2 SHELF - A4M05484
 (x1) 24"x14 13/16"x1" (25x376x610)





STEP 34- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

A9 HOSE BRACKET ASSEMBLY - A4M03060
(x1) 1 1/4"x1 7/16"x2 9/16" (31.5x36.5x65)




STEP 35- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 4 | H101292 | TORX PAN HEAD 1/4-20x13/32" |

A13 GAS TANK HOLDER ASSEMBLY - A4M03047
(x1) 1 15/16"x12 7/8"x14 3/4" (49x327x374)




A13 (x1)
GAS TANK HOLDER ASSEMBLY


1292 (x4)
TORX PAN HEAD 1/4-20x13/32"



**NOTE ORIENTATION OF
WING NUT TOWARDS FRONT**



STEP 36- CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


H4 BEAM - A4M05469
(x1) 31 7/16"x3 9/16"x1 3/8" (35x90x798)

- HARDWARE ATTACHES ON INSIDE OF CABINET

- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.



STEP 37- CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 6 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

T4 TABLETOP PANEL ASSEMBLY - A4M05470
 (x1) 31 7/16"x25"x1 9/16" (40x635x798)


- FLUSH BACK AND SIDES OF PANEL ASSEMBLY.

- ALIGN SLOTS IN TABLETOP WITH THREADED INSERTS IN SIDE AND BACK PANELS.


- SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.

- DO NOT USE TABLETOP SURFACE AS A WORK BENCH.


T4 LABEL ON BOTTOM
 SIDE INDICATES BACK



1202 (x6)
 TORX PAN HEAD 1/4-20x3/4 ASSY




T4 (x1)
 TABLETOP PANEL ASSEMBLY




STEP 38- CABINET ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 6 | H101103 | TORX SOCKET SCREW 1/4-20 |




STEP 39- FRIDGE CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

O8 VENTILATION PANEL - A4M03078
 (x1) 1 3/16"x3 3/4"x31 7/16" (30x95x798)

- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.




STEP 40- FRIDGE CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

S7 SIDE PANEL ASSEMBLY - A4M05475
(x1) 33 3/4"x25"x1 3/8" (35x635x857)




STEP 41- FRIDGE CABINET ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 9 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

G5 BACK PANEL ASSEMBLY - A4M05477
 (x1) 33 3/4"x25 13/16"x1 3/16" (30x655x857)




STEP 42- FRIDGE CABINET ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 9 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |


T5 TABLETOP PANEL ASSEMBLY - A4M05479
 (x1) 28 5/8"x25 5/16"x1 5/8" (41x643x727)

- FLUSH BACK AND SIDES OF PANEL ASSEMBLY.
- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.
- **ALIGH THREADED INSERTS ON TABLETOP WITH SLOTS IN SIDE AND BACK PANELS.**
- **SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.**
- **DO NOT USE TABLETOP SURFACE AS A WORK BENCH.**




1202 (x9)
 TORX PAN HEAD 1/4-20x3/4 ASSY


**T5 LABEL ON BOTTOM
 SIDE INDICATES BACK**



T5 (x)
 TABLETOP PANEL ASSEMBLY




STEP 43- CABINET DOOR ATTACHMENT



| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 6 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |


A4 RESTRICTIVE BRACKET - A4M06228
 (x1) 2 3/4"x7/8"x7/16"x7/16" (11.5x21.5x70)

A2 MAGNET BRACKET - A4M03026
 (x2) 1"x1 1/4"x3 1/8" (25x31x80)



STEP 44- POST ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



P02 FRONT POST ASSEMBLY - A4M05509
(x1) 4 3/4"x5 15/16"x89 1/2" (120x151x2274)



A01 BRACKET - A4M02018
(x2) 1"x1 5/16"x5 1/16" (25x33.2x128)

1202 (x4)
TORX PAN HEAD
1/4-20x3/4 ASSY


BRACKET HOLES
WILL FIT AROUND
THREADED INSERTS

NOTE THE 4
THREADED
INSERTS FOR
ORIENTATION

A01 (x1)
BRACKET


A01 (x1)
BRACKET

P02 (x1)
FRONT POST ASSEMBLY




STEP 45- POST ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




P01 FRONT POST ASEMBLY - A4M05508
(x1) 4 3/4"x5 15/16"x89 1/2" (120x151x2274)




A01 BRACKET - A4M02018
(x2) 1"x1 5/16"x5 1/16" (25x33.2x128)

**NOTE THE 4
THREADED INSERTS
FOR ORIENTATION**



STEP 46- POST ASSEMBLY


| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



P03 BACK POST ASSEMBLY - A4M05510
 (x1) 4 3/4"x5 15/16"x88 3/4" (120x151x2254)




A01 BRACKET - A4M02018
 (x1) 1"x1 5/16"x5 1/16" (25x33.2x128)




STEP 47- POST ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




P04 BACK POST ASSEMBLY - A4M05499
 (x1) 4 3/4"x5 15/16"x88 3/4" (120x151x2254)

A01 BRACKET - A4M02018
 (x1) 1"x1 5/16"x5 1/16" (25x33.2x128)




STEP 48- FRAME ASSEMBLY



POST ASSEMBLY FROM STEP 44

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

- WITH AT LEAST TWO OTHER PEOPLE, ATTACH FRONT POST ASSEMBLY TO CABINET.




STEP 49- FRAME ASSEMBLY






B04 SIDE BEAM - A4M02019
 (x1) 1 7/16"x5 1/4"x18 7/8" (36x134x480)

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




SIDE BEAM WILL BE AT A SLIGHT ANGLE



1202 (x2)
TORX PAN HEAD 1/4-20x3/4 ASSY


STEP 50- FRAME ASSEMBLY




POST ASSEMBLY FROM STEP 46

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 6 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

- WITH AT LEAST TWO OTHER PEOPLE, ATTACH BACK POST ASSEMBLY TO SIDE BEAM AND CABINET.




STEP 51- FRAME ASSEMBLY



POST ASSEMBLY FROM STEP 45

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




STEP 52- FRAME ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

B11 SIDE BEAM - A4M02106
 (x1) 1 7/16"x5 1/4"x18 7/8" (36x134x480)




STEP 53- FRAME ASSEMBLY




POST ASSEMBLY FROM STEP 47

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 6 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

- WITH AT LEAST TWO OTHER PEOPLE, ATTACH BACK POST ASSEMBLY TO SIDE BEAM AND CABINET.




STEP 54A - SINK INSTALLATION



A16 SINK ASSEMBLY - A4M03143
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)


1. INSTALLING THE SINK DRAIN

- SET DRAIN INSIDE OF SINK BODY, PLACING FOAM GASKET BETWEEN SURFACES.
- FASTEN IN PLACE USING RUBBER GASKET AND DRAIN NUT FROM BOTTOM SIDE.




2. INSTALLING THE FAUCET

- INSTALL FAUCET BY PLACING HANDLE AND SPOUT INTO SINK OPENINGS AND SECURING IN PLACE VIA NUT.
- INSERT SCREWS TO LOCK.
- CONNECT WATER FAUCET LINES TOGETHER.




3. INSTALLING THE DRAIN FITTING

- ATTACH DRAIN FITTING TO SINK DRAIN.




STEP 54B- SINK INSTALLATION



A16 SINK ASSEMBLY - A4M03143
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)


4. INSTALLING THE OVERFLOW DRAIN

- MAKE SURE RUBBER GASKET IS INSTALLED IN OVERFLOW DRAIN.
- INSERT DRAIN SCREW TO HOLD IN PLACE.




5. INSTALLING THE OVERFLOW DRAIN

- ATTACH OVERFLOW DRAIN BY CONNECTING EACH END AS SHOWN.




6. INSTALLING THE MAIN DRAIN AND TRAP

- ATTACH TRAP AND CORRUGATED DRAIN HOSE TO DRAIN FITTING.




STEP 54C- SINK INSTALLATION



A16 SINK ASSEMBLY - A4M03143
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)



3151 GARDEN HOSE ADAPTER - A4M03151
(x1)



A6P00796 SILICONE SEALANT
(x1)


- DRAIN STRAINER MUST BE USED WHEN DISCARDING FOOD INSIDE OF SINK.
- DO NOT LET SOLID MATERIAL ENTER SINK BASIN.

OPTIONS FOR WATER INLET SUPPLY HOOKUP:


- GARDEN HOSE ATTACHMENT USING PROVIDED ADAPTER
- WATER INLET SUPPLY LINE

OPTIONS FOR DRAIN DISCHARGE:

- BUCKET OR GREY WATER CONTAINER
- FRENCH DRAIN OR DRY BASIN
- INTEGRATED SEWER SYSTEM
- CHECK YOUR LOCAL REQUIRMENTS.




STEP 55- FRAME ASSEMBLY




CB1 W4L22000 CUTTING BOARD (x1)

CB1 W4L22000
CUTTING BOARD
(x1)




STEP 56- FRAME ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 8 | H101103 | TORX SOCKET SCREW 1/4-20 |

B01 SIDE BEAM - A4M02012
 (x1) 36x5 1/4"x46 1/2" (36x134x1181)




SIDE BEAM WILL BE AT A SLIGHT ANGLE


B01 (x1) SIDE BEAM



1103 (x8) TORX SOCKET SCREW 1/4-20



STEP 57- FRAME ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



B09 CORBEL - A4M02042
 (x1) 1 7/16"x6 11/16"x11 1/8" (36x170x282)

**SLIDE B09 ONTO
 A01 BRACKET**


**B09 (x1)
 CORBEL**

**A01 (x1)
 BRACKET**

**1202 (x4)
 TORX PAN HEAD 1/4-20x3/4 ASSY**





STEP 58- FRAME ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 8 | H101103 | TORX SOCKET SCREW 1/4-20 |

B05 SIDE BEAM - A4M02022
 (x1) 1 7/16"x5 1/4"x46 1/2" (36x134x1181)




STEP 59- FRAME ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

B08 CORBEL - A4M02041
 (x1) 1 7/16"x6 11/16"x11 1/8" (36x170x282)



STEP 60A- BACK BEAM ASSEMBLY



J2 SPLICE BRACKET - A4M05761
(x1) 1 5/16"x4 11/16"x39 3/8" (33.2x119.2x1000)



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 6 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



B02 BEAM ASSEMBLY - A4M05493
(x1) 1 7/16"x4 13/16"x77 3/8" (36x122x1965)

- BEAM AND SPLICE MUST BE ORIENTED AS SHOWN BELOW.
- SLIDE J2 INTO B02 AND LINE UP THREE HOLES TOP AND BOTTOM.
- FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAW HORSES FOR STEP 60A-60B.

1202 (x6)
TORX PAN HEAD 1/4-20x3/4 ASSY
HAND TIGHTEN ONLY




STEP 60B- BACK BEAM ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 6 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




B02 BEAM ASSEMBLY - A4M05493
 (x1) 1 7/16"x4 13/16"x77 3/8" (36x122x1965)

- SLIDE B02 ONTO SPLICE BRACKET.
- GENTLY TAP ENDS OF ASSEMBLY WITH RUBBER Mallet UNTIL GAP CLOSES, THEN TIGHTEN ALL BOLTS ON BEAM.




STEP 61- FRAME ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 8 | H101103 | TORX SOCKET SCREW 1/4-20 |



BACK BEAM ASSEMBLY FROM STEP 60A-60B

- ALIGN THRU HOLES IN BACK BEAM WITH THREADED INSERTS IN POSTS.
- ATTACH BACK BEAM TO POSTS.



STEP 62A- FRONT BEAM ASSEMBLY



J1 SPLICE BRACKET - A4M02230
 (x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 3 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




B03 BEAM ASSEMBLY - A4M05494
 (x1) 1 7/16"x5 1/4"x78 13/16" (36x134x2003)

- BEAM AND SPLICE MUST BE ORIENTED AS SHOWN BELOW.
- SLIDE J1 INTO B03 AND LINE UP THREE HOLES TOP AND BOTTOM.
- FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAW HORSES FOR STEP 62A-62B.

DO NOT ASSEMBLE BOLTS TO THE TOP SIDE OF BEAM, THESE BOLTS WILL BE ASSEMBLED IN LATER STEP


ARROW INDICATES TOP SURFACE OF BEAM



**1202 (x3)
 TORX PAN HEAD 1/4-20x3/4 ASSY
 HAND TIGHTEN ONLY**

**B03 (x1)
 BEAM ASSEMBLY**

**J1 (x1)
 SPLICE BRACKET**



STEP 62B- FRONT BEAM ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 3 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



B07 BEAM ASSEMBLY - A4M05496
 (x1) 1 7/16"x5 1/4"x78 13/16" (36x134x2003)

- SLIDE B07 ONTO SPLICE BRACKET.
- GENTLY TAP ENDS OF ASSEMBLY WITH RUBBER Mallet UNTIL GAP CLOSES, THEN TIGHTEN ALL BOLTS ON BEAM.


ARROWS INDICATE TOP SURFACE OF BEAM. BOTH ARROWS WILL FACE EACH OTHER ON BEAM ASSEMBLY

DO NOT ASSEMBLE BOLTS TO THE TOP SIDE OF BEAM, THESE BOLTS WILL BE ASSEMBLED IN LATER STEP

ALL THREADED INSERTS WILL BE ON THE SAME SIDE OF BEAMS

1202 (x3)
 TORX PAN HEAD 1/4-20x3/4 ASSY
 TIGHTEN ALL HARDWARE

B07 (x1)
 BEAM ASSEMBLY




STEP 63- FRAME ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 4 | H101103 | TORX SOCKET SCREW 1/4-20 |




FRONT BEAM ASSEMBLY FROM STEPS 62A-62B

- ALIGN THRU HOLES IN FRONT BEAM WITH THREADED INSERTS IN SIDE BEAMS.
- ATTACH FRONT BEAM TO SIDE BEAMS WITH SCREWS.




STEP 64- FRAME ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 4 | H101103 | TORX SOCKET SCREW 1/4-20 |


P05 BACK POST ASSEMBLY - A4M05507
(x1) 2 5/8"x7 7/8"x88 3/4" (66x200x2254)




STEP 65- FRAME ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

1202 (x4) **HAND TIGHTEN ONLY**
TORX PAN HEAD 1/4-20x3/4 ASSY




**ALIGN THREADED
INSERTS WITH
SLOTS IN SIDE PANEL**



BACK

FRONT


STEP 66- FRAME ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 14 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

B10 BACK WALL ASSEMBLY - A4M05491
 (x2) 1 7/16"x22 11/16"x23 3/8" (36x576.5x594)

- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.




STEP 67- FRAME ASSEMBLY




| Qty | PartNo | Description |
|-----|---------|--------------------------|
| 4 | H101103 | TORX SOCKET SCREW 1/4-20 |

P06 BACK POST ASSEMBLY - A4M05497
(x1) 2 5/8"x7 7/8"x88 3/4" (66x200x2254)




STEP 68- FRAME ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 4 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




STEP 69- FRAME ASSEMBLY



| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 14 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

B10 BACK WALL ASSEMBLY - A4M05491
 (x2) 1 7/16"x22 11/16"x23 3/8" (36x576.5x594)

- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.



STEP 70- ROOF ASSEMBLY


| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 24 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



R01 RAFTER - A4M02020
(x6) 3 1/8"x3 15/16"x45 1/16" (80x100x1144)

-ATTACH EACH RAFTER AS SHOWN BELOW

1202 (x24)
TORX PAN HEAD 1/4-20x3/4 ASSY




ARROW FACE UP
AND TOWARDS
FRONT OF GAZEBO

BRACKET HOLES
WILL FIT AROUND
THREADED INSERTS

R01 (x6)
RAFTER


BACK

FRONT




STEP 71- ROOF ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------------|
| 4 | H101132 | TORX SOCKET SCREW SHORT 1/4-20 |
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



E04 PURLIN ASSEMBLY - A4M05501
 (x1) 1 9/16"x1 3/4"x87 13/16" (40x45x2230)

- DO NOT STAND ON CABINET FRAME TO INSTALL PURLIN.
- WITH ONE EXTRA PERSON, ATTACH E04 PURLIN.



STEP 72- ROOF ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------------|
| 1 | H101132 | TORX SOCKET SCREW SHORT 1/4-20 |
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



E03 PURLIN ASSEMBLY - A4M05495
(x1) 1 9/16"x1 3/4"x23 3/8" (40x45x594)

- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.

1202 (x2)
TORX PAN HEAD
1/4-20x3/4 ASSY

BRACKET HOLES
WILL FIT AROUND
THREADED INSERTS


1132 (x1)
TORX SOCKET
SCREW SHORT 1/4-20

PILOT HOLES
FACE UP

E03 (x1)
PURLIN ASSEMBLY

BACK

FRONT




STEP 73- ROOF ASSEMBLY




E03 PURLIN ASSEMBLY - A4M05495
(x1) 1 9/16"x1 3/4"x23 3/8" (40x45x594)

| Qty | PartNo | Description |
|-----|---------|--------------------------------|
| 1 | H101132 | TORX SOCKET SCREW SHORT 1/4-20 |
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL HARDWARE IN THIS STEP.



STEP 74- ROOF ASSEMBLY




530 2-WAY SQUARE PLUG - A6P00530
(x2)




E01 PURLIN ASSEMBLY - A4M05502
(x2) 1 9/16"x8 7/8"x66 3/16" (40x45x1681.25)

- ATTACH 2-WAY PLUG(530) TO ENDS OF E01 PURLIN.
- USE A RUBBER Mallet TO TAP 2-WAY SQUARE PLUG INTO ENDS OF PURLINS.




STEP 75A- ROOF ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------------|
| 4 | H101132 | TORX SOCKET SCREW SHORT 1/4-20 |
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |



PURLIN ASSEMBLY(x2)
FROM STEP74

-STARTING AT FRONT WORKING TO BACK WILL MAKE IT EASIER TO INSTALL PURLIN ASSEMBLIES




STEP 75B -ROOF ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|--------------------------------|
| 8 | H101132 | TORX SOCKET SCREW SHORT 1/4-20 |
| 2 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |




E02 PURLIN ASSEMBLY - A4M05503
(x2) 1 9/16"x19 15/16"x88 1/2" (40x45x2248.3)

- WITH ONE EXTRA PERSON, ATTACH E01 PURLINS TO THE 2-WAY PLUGS.
- STARTING AT FRONT AND WORKING TO BACK WILL MAKE IT EASIER TO INSTALL PURLIN ASSEMBLIES.



STEP 76- ROOF ASSEMBLY




3113 29GA STEEL SHEETING - A4M03113
(x3) 1/4"x18 7/8"x46 7/16" (7x480x1179)

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 12 | H101117 | SCREW WOODGRIP 10-16x3/4" BLK |


- REMOVE PROTECTIVE FILM.

- WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.




STEP 77- ROOF ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 12 | H101117 | SCREW WOODGRIP 10-16x3/4" BLK |




3113 29GA STEEL SHEETING - A4M03113
(x2) 1/4"x18 7/8"x46 7/16" (7x480x1179)




5500 29GA STEEL SHEETING - A4M05500
(x1) 1/4"x13"x46 7/16" (7x330x1179)

- REMOVE PROTECTIVE FILM.

- WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.



STEP 78- ROOF ASSEMBLY




29GA STEEL SHEETING - A4M03113
(x3) 1/4"x18 7/8"x46 7/16" (7x480x1179)

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 12 | H101117 | SCREW WOODGRIP 10-16x3/4" BLK |

- REMOVE PROTECTIVE FILM.

- WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.



STEP 79- HOLE COVER ASSEMBLY




1352 HOLE COVER - A4M01352
(x8)




H2 WOOD GRAIN HOLE COVER - A4M02078
(x28)

- USE A SMALL PIECE OF WOOD AND RUBBER Mallet TO TAP HOLE COVERS IN.
- DO NOT TAP DIRECTLY WITH A HAMMER AS YOU MAY DAMAGE THE POWDER COAT FINISH ON PRODUCT.




STEP 80A- ROOF ASSEMBLY



5504 DRIP EDGE - A4M05504
(x2) 1 1/2"x3 5/16"x76 11/16" (0.5x84x1948)

3118 DRIP EDGE SPLICE - A4M03118
(x1) 1 11/16"x3 7/16"x3 15/16" (0.5x88x100)


- REMOVE PROTECTIVE FILM.
- WITH ONE EXTRA PERSON, ORIENT 5504, 3118 UNDER THE SHEETS AS BELOW SHOWN.




STEP 80B- ROOF ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 18 | H101117 | SCREW WOODGRIP 10-16x3/4" BLK |

- **WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.**
- **DUE TO MULTIPLE LAYERS OF METAL ON THE DRIP EDGE, IT IS RECOMMENDED THAT A 1/8" (3mm) DRILL BIT BE USED TO CREATE STARTER HOLES.**



STEP 81- ROOF ASSEMBLY




3114 DRIP EDGE - A4M03114
(x2) 7/16"x3 1/8"x46 1/4" (11x79x1175)

| Qty | PartNo | Description |
|-----|---------|------------------------------|
| 6 | H101116 | SCREW SELF TAPPING 1/4x1 BLK |



- REMOVE PROTECTIVE FILM.

- DUE TO MULTIPLE LAYERS OF METAL ON THE DRIP EDGE, IT IS RECOMMENDED THAT A 1/8" (3mm) DRILL BIT BE USED TO CREATE STARTER HOLES.

- WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.



STEP 82A - ROOF ASSEMBLY




5505 DRIP EDGE - A4M05505
(x1) 3/16"x3 7/16"x78 1/4" (6x88x1987)

3122 DRIP EDGE SPLICE - A4M03122
(x1) 3/16"x3 1/2"x3 15/16" (6x90x100)

5506 DRIP EDGE - A4M05506
(x1) 3/16"x3 7/16"x78 1/4" (6x88x1987)

- REMOVE PROTECTIVE FILM.
- WITH ONE EXTRA PERSON, ORIENT 3122, 5505 AND 5506 AS BELOW SHOWN.




STEP 82B- ROOF ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-------------------------------|
| 10 | H101116 | SCREW SELF TAPPING 1/4x1 BLK |
| 6 | H101202 | TORX PAN HEAD 1/4-20x3/4 ASSY |

- ATTACH SCREWS TO DRIP TRIM AND TIGHTEN ALL HARDWARE.


- DUE TO MULTIPLE LAYERS OF METAL ON THE TRIM SPLICE, IT IS RECOMMENDED THAT A 1/8" (3mm) DRILL BIT BE USED TO CREATE STARTER HOLES.

- WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.



STEP 83A- TRASH CAN INSTALLATION

| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 6 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |




H3 TRASH CAN BRACKET ASSEMBLY - A4M05490
 (x1) 18"x13 5/16"x1 3/8" (35x337x458)



A11 TRIANGLE PANEL - A4M03086
 (x2) 13/16"x13 3/4"x13 3/4" (20x350x350)

- IT IS RECOMMENDED TO USE THE 6" MAGNETIC DRIVER EXTENSION PROVIDED IN YOUR HARDWARE KIT FOR THIS STEP.



STEP 83B - TRASH CAN INSTALLATION




| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 9 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |

D3 DRAWER PANEL ASSEMBLY - A4M05464
(x1) 22 7/16"x15 1/8"x7/8" (22x384x570)

- IT IS RECOMMENDED TO USE THE 6" MAGNETIC DRIVER EXTENSION PROVIDED IN YOUR HARDWARE KIT FOR THIS STEP.

D3 (x1)
DRAWER PANEL ASSEMBLY

1289 (x9)
PAN HEAD SCREW
8-32x1/2" SS





STEP 84- TRASH CAN INSTALLATION




TRASH CAN ASSEMBLY STEPS FROM 83A-83B

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH TRASH CAN ASSEMBLY BY ALIGNING BOTH ENDS OF FACTORY ASSEMBLED DRAWER SLIDES WITH ONE ANOTHER.
- PRESS TOGETHER UNTIL DRAWER SLIDES CONNECT.




STEP 85- DRAWER ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|-----------------------------|
| 9 | H101289 | PAN HEAD SCREW 8-32x1/2" SS |



D7 DRAWER BODY ASSEMBLY - A4M05489
(x1) 22 9/16"x13 1/4"x7 1/8" (181x337x573)




D4 DRAWER PANEL ASSEMBLY - A4M05465
(x1) 15 1/8"x10 15/16"x7/8" (22x278x384)

- ALIGN THROUGH HOLES IN DRAWER BODY WITH THREADED INSERTS IN DRAWER PANEL.


1289 (x9)
PAN HEAD SCREW 8-32x1/2" SS

D7 (x1)
DRAWER BODY ASSEMBLY

D4 (x1)
DRAWER PANEL ASSEMBLY




STEP 86- DRAWER ASSEMBLY




DRAWER ASSEMBLY FROM STEP 85

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH DRAWER ASSEMBLY BY ALIGNING BOTH ENDS OF FACTORY ASSEMBLED DRAWER SLIDES WITH ONE ANOTHER.
- PRESS TOGETHER UNTIL DRAWER SLIDES CONNECT.



STEP 87- DOOR ASSEMBLY

| Qty | PartNo | Description |
|-----|---------|----------------------------------|
| 24 | H101185 | PHILLIPS FLAT HEAD 8-32x.5 SCREW |



D1 DOOR ASSEMBLY - A4M05487
(x1) 22 3/8"x18 7/8"x7/8" (22x480x568)



D2 DOOR ASSEMBLY - A4M05488
(x1) 22 3/8"x18 7/8"x7/8" (22x480x568)



D5 DOOR ASSEMBLY - A4M05472
(x1) 22 3/8"x15 1/2"x7/8" (22x393.5x569)




D6 DOOR ASSEMBLY - A4M05471
(x1) 22 3/8"x15 1/2"x7/8" (22x393.5x569)



D8 DOOR ASSEMBLY - A4M05480
(x1) 33 1/2"x12 11/16"x7/8" (22x324.1x851)




D9 DOOR ASSEMBLY - A4M05481
(x1) 33 1/2"x12 11/16"x7/8" (22x322x851)




A4M05760 HINGE ASSEMBLY
(x12)

- INSTALL CABINET HINGES TO ALL DOORS.
- DO NOT OVERTIGHTEN HARDWARE.
- REPEAT FOR ALL DOOR ASSEMBLIES IN THIS STEP.




STEP 88- CABINET DOOR ATTACHMENT



D2 DOOR ASSEMBLY - A4M05488
(x1) 22 3/8"x18 7/8"x7/8" (22x480x568)

| Qty | PartNo | Description |
|-----|---------|----------------------------------|
| 8 | H101185 | PHILLIPS FLAT HEAD 8-32x.5 SCREW |


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.




D2 (x1)
DOOR ASSEMBLY

**ALIGN HINGE BRACKET WITH
THREADED INSERTS IN PANEL**

1185 (x8)
PHILLIPS FLAT HEAD 8-32x.5 SCREW
DO NOT OVERTIGHTEN HARDWARE





STEP 89- CABINET DOOR ATTACHMENT



| Qty | PartNo | Description |
|-----|---------|----------------------------------|
| 8 | H101185 | PHILLIPS FLAT HEAD 8-32x.5 SCREW |

D1 DOOR ASSEMBLY - A4M05487
(x1) 22 3/8"x18 7/8"x7/8" (22x480x568)


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



**ALIGN HINGE BRACKET WITH
THREADED INSERTS IN PANEL**

**1185 (x8)
PHILLIPS FLAT HEAD 8-32x.5 SCREW
DO NOT OVERTIGHTEN HARDWARE**


STEP 90- CABINET DOOR ATTACHMENT




| Qty | PartNo | Description |
|-----|---------|----------------------------------|
| 8 | H101185 | PHILLIPS FLAT HEAD 8-32x.5 SCREW |

D5 DOOR ASSEMBLY - A4M05472
(x1) 22 3/8"x15 1/2"x7/8" (22x393.5x569)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



D5 (x1)
DOOR ASSEMBLY



**ALIGN HINGE BRACKET WITH
THREADED INSERTS IN PANEL**

**1185 (x8)
PHILLIPS FLAT HEAD 8-32x.5 SCREW
DO NOT OVERTIGHTEN HARDWARE**


STEP 91- CABINET DOOR ATTACHMENT



| Qty | PartNo | Description |
|-----|---------|----------------------------------|
| 8 | H101185 | PHILLIPS FLAT HEAD 8-32x.5 SCREW |

D6 DOOR ASSEMBLY - A4M05471
(x1) 22 3/8"x15 1/2"x7/8" (22x393.5x569)


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



D6 (x1)
DOOR ASSEMBLY

**ALIGN HINGE BRACKET WITH
THREADED INSERTS IN PANEL**

1185 (x8)
PHILLIPS FLAT HEAD 8-32x.5 SCREW
DO NOT OVERTIGHTEN HARDWARE





STEP 92- CABINET DOOR ATTACHMENT



D9 DOOR ASSEMBLY - A4M05481
(x1) 33 1/2"x12 11/16"x7/8" (22x322x851)

| Qty | PartNo | Description |
|-----|---------|----------------------------------|
| 8 | H101185 | PHILLIPS FLAT HEAD 8-32x.5 SCREW |


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



**ALIGN HINGE BRACKET WITH
THREADED INSERTS IN PANEL**

**1185 (x8)
PHILLIPS FLAT HEAD 8-32x.5 SCREW
DO NOT OVERTIGHTEN HARDWARE**


STEP 93- CABINET DOOR ATTACHMENT



| Qty | PartNo | Description |
|-----|---------|----------------------------------|
| 8 | H101185 | PHILLIPS FLAT HEAD 8-32x.5 SCREW |

D8 DOOR ASSEMBLY - A4M05480
 (x1) 33 1/2"x12 11/16"x7/8" (22x324.1x851)


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



D8 (x1)
DOOR ASSEMBLY

**ALIGN HINGE BRACKET WITH
THREADED INSERTS IN PANEL**




1185 (x8)
PHILLIPS FLAT HEAD 8-32x.5 SCREW
DO NOT OVERTIGHTEN HARDWARE



STEP 94- CABINET DOOR ADJUSTMENT(AS NEEDED)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ADJUST HINGES (AS NEEDED) SO THAT THE GAP AROUND ALL DOORS IS THE SAME AND THERE IS NO INTERFERENCE BETWEEN DOORS AND CABINETS.
- ADJUST MAGNET CATCH BRACKETS AS NEEDED.


**LOOSEN SCREWS TO ADJUST
MAGNET BRACKET, UNTIL IT
COMES IN CONTACT WITH
DOOR IN THE SHUT POSITION**



**SCREW #2:
LOOSEN THESE SCREWS TO
SLIDE DOOR TOWARD CABINET
OR AWAY FROM CABINET**


**SCREW #1:
SCREW CLOCKWISE TO BRING
EDGE OF DOOR AWAY FROM
CABINET. SCREW COUNTER
CLOCKWISE TO BRING EDGE OF
DOOR CLOSER TO CABINET**

STEP 95- KITCHEN ACCESSORY




A4M02290 MAGNETIC PAPER TOWEL HOLDER
(x1)

- MAGNETIC PAPER TOWEL HOLDER CAN BE ATTACHED TO ANY METAL SURFACE ON KITCHEN.
- WE RECOMMEND ATTACHING TO THE INSIDE OF CABINET DOOR.
- **MAKE SURE TO KEEP PAPER TOWEL HOLDER AT A SAFE DISTANCE FROM GRILLING SURFACE.**



2290 (x1)
MAGNETIC PAPER
TOWEL HOLDER

STEP 96- KITCHEN ACCESSORY






A7 BACK SHELF - A4M06229
(x4) 2 7/16"x7 15/16"x17 11/16" (61x201x450)




A6P00679 EVA TAPE
(x16)

APPLY EVA TAPE IN THE APPROXIMATE LOCATIONS SHOWN
REPEAT FOR ALL A7 SHELVES




STEP 97- KITCHEN ACCESSORY



A7 BACK SHELF - A4M06229
(x4) 2 7/16"x7 15/16"x17 11/16" (61x201x450)


SLIDE BACK SHELF OVER ANY TUBE ALONG B10 BACK PANEL. SHELVES CAN BE POSITIONED ANYWHERE DESIRED.




STEP 98- KITCHEN ANCHORING

| Qty | PartNo | Description |
|-----|---------|----------------------|
| 14 | H100120 | CONCRETE ANCHOR |
| 14 | H100630 | WASHER FLAT 8x19 BLK |

- MANUFACTURER RECOMMENDS INSTALLATION ON CONCRETE SURFACE OR CONCRETE POST PADS AS SHOWN BELOW.
- FOR INSTALLATION ON WOOD DECK, YOU MUST ENSURE THERE IS AMPLE STRUCTURAL SUPPORT UNDER THE DECK. HARDWARE NOT INCLUDED FOR DECK ATTACHMENT.
- **PRE-DRILL HOLES FOR CONCRETE ANCHORS USING A 3/16" (5mm) CONCRETE DRILL BIT.**




OUTDOOR KITCHEN FRIDGE






9230132 OUTDOOR KITCHEN FRIDGE - LEFT OPEN
(x1)

- FOR INSTALLATION OF OUTDOOR KITCHEN FRIDGE, REFER TO PAGES IN THIS INSTRUCTION MANUAL.
- FOR DETAILED INFORMATION OF OUTDOOR KITCHEN FRIDGE, REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH THE OUTDOOR KITCHEN FRIDGE.
- FOLLOW DIRECTIONS FOR PROPER CARE AND USE.





OUTDOOR KITCHEN FRIDGE

- CAREFULLY SLIDE FRIDGE INTO CABINET OPENING MAKING SURE THAT THE ELECTRICAL CORD IS ROUTED THROUGH THE HOLES IN THE SIDE PANELS OF THE CABINET.
- IF FRIDGE IS NOT IN UPRIGHT POSITION, PLEASE LET SIT FOR 24 HRS BEFORE PLUGGING INTO RECEPTACLE.
- FRIDGE CANNOT BE CONNECTED TO ELECTRICAL ENCLOSURE ATTACHED TO OUTDOOR STRUCTURE.




OUTDOOR KITCHEN FRIDGE

- ALIGN FEET ON FRIDGE UNIT SO THAT IT IS LEVEL AND DOES NOT TILT.
- TURN FEET CLOCKWISE TO EXTEND THEM AND COUNTERCLOCKWISE TO SHORTEN. REPEAT THIS FOR ALL FOUR FRIDGE FEET AS NEEDED TO LEVEL.



FOR APPLIANCE INSTALLATION REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH EACH INDIVIDUAL APPLIANCE. FOLLOW DIRECTIONS FOR PROPER INSTALLATION.



9205413 | **ELECTRICAL ENCLOSURE**
(x1)

FOR POWERPORT INSTALLATION REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH THE POWERPORT KIT. INSTALL ON ANY EXTERIOR POST THAT IS DESIRED. FOLLOW DIRECTIONS FOR PROPER INSTALLATION.