


Item # : TW70TRS

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkerediton.com


Revised 01/09/2020(C)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.


















- VIII. Drill may be needed for securing product to wall.

Parts List



Hardware List


A		Ø10x30mm	Wooden dowel	14	pcs
B		M6x45mm	Bolt	8	pcs
C		M6x35mm	Bolt	16	pcs
D			Flat washer	16	pcs
E			Lock washer	16	pcs
F		Ø4x50mm	Screw	8	pcs
G		Ø4x32mm	Screw	65	pcs
H		Ø4x12mm	Screw	16	pcs
J		Ø5x14mm	Screw	16	pcs
K			Buckle hook	4	pcs
L			Buckle lock	4	pcs
M		M 4	Hex key	1	pc
N			Glue tube	2	pcs
P			Metal plate	2	pcs



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) into parts (4,5,6) as per diagram.

Step 2




Place parts (1,3) into part (2) as per diagram.

Step 3




Using screw (H) attach Buckle hook (K) to part (2) with Philips head screwdriver as per diagram.

Step 4




Using screw (H) attach Buckle lock (L) to parts (1,3) with Philips head screwdriver as per diagram.

Step 5




Insert part (6) into parts (4) ,then using screw(G) secure part (6) to parts (4) with Philips head screwdriver as per diagram.

Step 6




Insert parts (4,6) to parts (1,2,3) as per diagram.

Step 7




Using screw (G) attach parts (5,6) to parts (1,2,3) with Philips head screwdriver as per diagram.

Step 8




Using screw (G) attach part (4) to parts (1,3) with Philips head screwdriver as per diagram.

Step 9





Using screw (G) attach parts (7) to parts (4,5) , then secure parts (4,5,6) to parts (1,2,3) with Philips head screwdriver as per diagram.

Step 10



Insert parts (9,10) to part (11) ,then place part (12) to parts (9,10) as per diagram.


Step 11



x 2


Using screw (F) attach parts (9,10) to parts (11,12) with Philips head screwdriver as per diagram.

Step 12




Using bolt (B) attach part (8) to parts (11,12) with Hex key (M) as per diagram.

Step 13




Using screw (G) attach part (9) to part (8) ,then using screw (J) attach metal plate (P) to part (10) with Philips head screwdriver as per diagram.

Step 14




Using bolt (C) attach lock washer (D) and Flat washer (E) into part (8) to parts (1,2,3) with Hex key (M) as per diagram.

Step 15




Connect and secure part (13) to part (14) , If necessary , adjustable parts (13,14) turn left or right as per diagram.

Step 16



Using screw (J) secure part (13) to part(10) with Philips head screwdriver as per diagram.

Step 17



Final Assembly