


# Item: ELIB4C

## Assembly Instructions




Please visit our website for the most current instructions, assembly tips, to report damage or request parts. [www.walkeredison.com](http://www.walkeredison.com)


Revised 08/2024-V3

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product.



- VI. Power tools should not be used to assemble this product.
















# Parts List




Part #	Description	Qty
07	Back panel	01 pc
24	Bottom panel	01 pc
25	Shelf	01 pc
26	Foot	04 pcs
27	Drawer bottom	01 pc
29	Left drawer side	01 pc

Part #	Description	Qty
30	Right drawer side	01 pc
42	Right side panel	01 pc
43	Left side panel	01 pc
44	Drawer front	01 pc
45	Top panel	01 pc
46	Drawer back	01 pc

# Hardware List

A		ø8*30mm	Wooden dowel	22 pcs
B		ø3,5*20mm	Screw	06 pcs
C		ø3,5*30mm	Screw	04 pcs
D		ø4,0*40mm	Screw	06 pcs
E		ø15*12mm	Cam Lock	10 pcs
F		ø6,0*8mm	Screw	06 pcs
G		ø3,5*14mm	Screw	08 pcs
H		ø7,0*80mm	Bolt	04 pcs
I		ø5,0*24mm	Cam Bolt	10 pcs
J			Handle	01 pcs
K			Hex key	01 pc
L		ø26mm	Plastic fixing device	06 pcs
M		ø33mm	Cover	06 pcs

Phillips head screwdriver required  
for assembly (not included)



*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Hardware List


N		ø30mm	Felt sticker	04 pcs
O		ø250mm	Right Drawer slide support	01 pc
P		ø250mm	Left Drawer slide support	01 pc
Q		ø250mm	Right Drawer slide	01 pc
R		ø250mm	Left Drawer slide	01 pc

# Step 1


Insert wooden dowel (A) into parts 25, 26, 29, 30, 42 e 43.




Please assemble on a clean soft surface to avoid damage.





Please assemble on a clean soft surface to avoid damage.




# Step 2







1 - Ensure cam bolt is installed straight and not at an angle.  
2 - Tighten cam bolt until shoulder on cam bolt is flush. Do not over-tighten.



Insert Cam Bolts (I) with a Phillips head screwdriver into parts 42, 43 and 44.



# Step 3







L		06
		ø26mm

Insert Plastic fixing device (L) into parts 42 and 43.

# Step 4

Secure right side slide support (O) to part 42 with screw (F) and phillips head screwdriver






F		06
		ø6,0*8mm
O		01
		ø250mm
P		01
		ø250mm

Secure left side slide support (P) to part 43 with screw (F) and phillips head screwdriver

# Step 5



Use a phillips screwdriver to fix the screw (G) into the right side slide and left side slide.




G		02
		ø3,5x14mm

# Step 6


Secure part 45 to part 42. Insert screw (B) into Plastic fixing device (L) and tighten with a Phillips head screwdriver.



B		03
		ø3,5*20mm




# Step 7




Align the opening in cam lock to the cam bolt and press into opening. Using a screwdriver, rotate the cam lock until it engages with the cam bolt and locks in place (anywhere between 90-180 degrees). Do not over-tighten the cam lock. Doing so may result in damaged or broken parts.

Secure part 25 to part 42. Insert cam locks (E) into part 25 and tighten with a Phillips head screwdriver.




E		03
<small>ø15*12mm</small>		

# Step 8



Align the opening in cam lock to the cam bolt and press into opening. Using a screwdriver, rotate the cam lock until it engages with the cam bolt and locks in place (anywhere between 90-180 degrees). Do not over-tighten the cam lock. Doing so may result in damaged or broken parts.




Secure part 43 to part 45 using the wooden dowels and holes. Fit the cam bolts (I) on part 25 to the cam bolt holes on part 43. Insert cam locks (E) into part 25 and tighten with Phillips head screwdriver.



E		03
<small>ø15*12mm</small>		



## Step 9

Secure part 43 to part 45. Insert screw (B) into Plastic fixing device (L) and tighten with a Phillips head screwdriver.




## Step 10

Insert part 07 between parts 42 and 43.




# Step 11

Insert bolt (H) into part 24 and 26, and tighten with hex key (K).






# Step 12

Secure part 24 to parts 42 and 43 with screw (D) and tighten with a Phillips head screwdriver.




D		06
<small>ø4,0*40mm</small>		



# Step 13





Remove the felt sticker from the paper.  
Glue the felt to the bottom of the foot.




# Step 14




Secure parts 29 and 30 to part 44 using Cam Lock (E) and tighten with a Phillips head screwdriver.




# Step 15




1st



2nd






Insert part 27 between parts 29 and 30.



Insert part 46 between parts 29 and 30. Secure part 46 to parts 29 and 30 with screw (C) and phillips head screwdriver.

C		04
<small>ø3,5*30mm</small>		

# Step 16



Attach handle (J) with screw (G) and Phillips head screwdriver.










G		02
<small>ø3,5x14mm</small>		
J		01

# Step 17

Secure Right drawer slide (Q) into part 30 with screw (F), tighten with a Phillips head screwdriver.




Secure Left drawer slide (R) into part 29 with screw (F), tighten with a Phillips head screwdriver.

Rotate 90°



# Step 18

Insert Cover (M) into Plastic fixing device (L) in the parts 42 and 43.



# Step 19

## Assembly Complete!

