


PREPARATION

1. Record your model number for future reference.
2. **DANGER: Risk of electric shock.** To avoid electric shock, the power must be turned off at the circuit breaker or fuse box before beginning the installation procedure.
3. **DANGER: Risk of electric shock.** To avoid electric shock, the outlet box must be properly grounded.
4. **Important Information.** Inspect the product for any damages. This product is for indoor use only. Observe all local codes.
5. Your product may appear different than the one illustrated. The installation procedures remain the same.



Please see next page for a larger installation image

TOOLS AND MATERIALS NEEDED



FIXTURE INSTALLATION

1. Remove the fixture and parts bag(s) from the carton. Put them onto a clean and soft cloth to protect finish. Confirm all parts are included.
2. Attach mounting plate (B) onto outlet box with screws (C). Ground screw (J) is as shown.
3. Thread wire (F) through rod (E) and canopy (D). Install the rod (E) onto fixture (G) by turning until the connection is tight, then install the rod (E) and canopy (D) by turning until the connection is tight.
4. **NOTICE:** To avoid short circuit, make sure wires are not exposed. Fasten the DC output red wire on driver to the red wire on fixture wire (F) with wire nut (H). Wrap the wire connector with electrical tape so that the tape seals the end of wire nut (H), see diagram.
5. **NOTICE:** To avoid short circuit, make sure wires are not exposed. Fasten the DC output blue wire on driver to the blue wire on fixture wire (F) with wire nut (H). Wrap the wire connector with electrical tape so that the tape seals the end of wire nut (H), see diagram.
6. **NOTICE:** To avoid short circuit, make sure wires are not exposed. Fasten fixture green or bare ground wire to the green or bare copper wire in outlet box with wire nut (A) or fasten onto ground screw (J) on mounting plate.
7. **NOTICE:** To avoid short circuit, make sure wires are not exposed. Fasten AC input white wire on driver to the white wire in outlet box with wire nut (A). Wrap the wire connector with electrical tape so that the tape seals the end of wire nut (A), see diagram.
8. **NOTICE:** To avoid short circuit, make sure wires are not exposed. Fasten the AC input black wire on driver to the black wire in outlet box with wire nut (A). Wrap the wire connector with electrical tape so that the tape seals the end of wire nut (A), see diagram.
9. Tuck wires carefully inside outlet box. Attach the canopy (D) onto mounting plate (B) by securing screws (I).
10. Restore power to circuit at breaker or fuse box.



WARNING: For dimming of this fixture, only compatible dimming devices as outlined on the spec sheet are allowed. Visit www.kohler.com to view the spec sheet.

CLEANING

Please clean fixture with a soft and dry cloth ONLY. Clean glass with a mild soap.

