



OWNER'S MANUAL

**Force 100/150/200
Folding Scooter**

IMPORTANT! You must read the Mongoose owner's manual before taking your first ride. It contains crucial information about safety, performance, proper use, and maintenance.



Proper assembly and operation of your scooter is important for your safety and enjoyment. If you have questions or need advice regarding assembly, parts, performance, or returns, please contact us. Enjoy the ride!

**Do not return this item to the store.
Please contact Consumer Care
if you need assistance:**

help.mongoose.com

Text: 1-866-450-0414

Call: 1-800-626-2811

Monday-Friday, 8 AM-6 PM Central Time

Contents

1. Introduction	2
A. About This Manual	2
B. A Special Note For Parents and Guardians	2
2. Safety	3
A. General Safety	4
B. Road Conditions	4
C. Cornering Technique	4
D. Safe Riding Rules for Children	4
E. Protective Gear and Clothing	5
3. Recommended Rider	5
4. Assembly	6
5. Use	12
6. Maintenance	12

1. Introduction

A. About This Manual

It is important for you to understand your new scooter. By reading this manual before you go out on your first ride, you'll know how to get better performance, comfort, and enjoyment from your new scooter. It is also important that your first ride on your new scooter is taken in a controlled environment, away from cars, obstacles and cyclists.

This manual contains important information regarding safety, assembly, use, and maintenance of the scooter but is not intended to be a complete or comprehensive manual covering all aspects concerning scooter ownership. We recommend consulting an expert if you have any doubts or concerns regarding your experience or ability to properly assemble and maintain the scooter.

B. A Special Note For Parents and Guardians

It is a tragic fact that most scooter accidents involve children. As a parent or guardian, you bear the responsibility for the activities and safety of your minor child. Among these responsibilities are to make sure that the scooter which your child is riding is properly fitted to the child; that it is in safe operating condition; that you and your child have learned, understand and obey not only the applicable local motor vehicle, scooter, and traffic laws, but also the common sense rules of safe and responsible scooting. As a parent, you should read this manual before letting your child ride the scooter. Please make sure that your child always wears an approved helmet when riding.

2. Safety

Read and understand all product & safety warnings. Failure to heed the warnings in this manual increases risk of serious injury. Using your scooter safely depends upon your diligence in following the warnings, cautions, and instructions in this owner's manual. Using your scooter safely also depends upon your own good judgment and/or common sense, as well as that of your provider, caregiver, and/or healthcare professional. Pacific Cycle is not responsible for injuries and/or damage resulting from any person's failure to follow the warnings, cautions, and instructions in this owner's manual.



WARNING: Persons with the following conditions are cautioned not to operate: those with heart conditions; pregnant women; persons with head, back, or neck ailments, or prior surgeries to those areas of the body; and persons with any mental or physical conditions that may make them susceptible to injury or impair their physical dexterity or mental capabilities to recognize, understand, and perform all of the safety instructions and to be able to assume the hazards inherent in unit use.



WARNING: Always wear safety equipment such as helmet, knee pads and elbow pads. Always wear a helmet when riding your scooter and keep the chinstrap securely buckled. Always wear shoes.



WARNING: Ride on smooth, paved surfaces away from motor vehicles. Avoid sharp bumps, drainage grates, and sudden surface changes. Avoid streets and surfaces with water, sand, gravel, dirt, leaves, and other debris. Wet weather impairs traction, braking, and visibility.



WARNING: Obey all local traffic and scooter riding laws and regulations. Do not ride at night. Operate only with adequate daylight conditions of visibility. Do not perform racing, stunt riding, or other maneuvers, which may cause loss of control, or may cause uncontrolled actions or reactions.



WARNING: Keep fingers and other body parts away from all moving components. Brake will get hot from continuous use. Do not touch after braking.



WARNING: Adult supervision required. Adults must assist children in the initial adjustment procedures to unfold scooter, adjust handlebar and steering to height, and finally to fold scooter.



WARNING: Never allow more than one rider. Never hitch on to another vehicle and never pull anyone or anything.



WARNING: Check and secure all fasteners before every ride. Replace worn or broken parts immediately.



WARNING: Riding the scooter in unsafe conditions (i.e.: at night), in an unsafe manner, or disregarding traffic laws may result in an unexpected movement, loss of control, and serious injury or death.

A. General Safety

- Familiarize yourself with all the scooter's features before riding. Practice braking.
- Expect the unexpected (e.g., opening car doors or cars backing out of concealed driveways). Watch out for pedestrians.
- Maintain a comfortable stopping distance from all other riders, vehicles and objects. Safe braking distances and forces are subject to the prevailing weather conditions.
- Use original spare parts only. Do not make structural changes or modifications to the scooter. Replace worn or broken parts immediately.
- Wear proper riding attire, reflective if possible, and avoid open toe shoes.
- Do not use items that may restrict your hearing and vision.
- Do not allow passengers and do not carry packages that will interfere with your visibility or control.
- Do not ride indoors or on surfaces that could be damaged such as carpet or flooring.

B. Road Conditions

- Be aware of road conditions. Concentrate on the path ahead. Avoid pot holes, gravel, wet road markings, oil, curbs, speed bumps, drain grates and other obstacles.
- Cross train tracks at a 90 degree angle or walk your scooter across.
- Avoid sharp bumps, drainage grates and sudden surface changes.
- Wet weather impairs traction, braking and visibility.

C. Cornering Technique

- Brake slightly before cornering and prepare to lean your body into the corner.
- Decrease your riding speed, avoid sudden braking and sharp turns.

D. Safe Riding Rules for Children

- Be aware of other vehicles behind and nearby.
- If riding downhill, be extra careful. Slow down using the brakes and maintain control of the steering.
- Stunt riding reduces ability to control and maneuver the scooter. Videos may show people doing stunts or tricks. Do not assume you can attempt the same tricks without risk to you and the scooter.
- Keep both hands on handlebars at all times.

E. Protective Gear and Clothing



WARNING: Riding a scooter without protective gear, clothing, shoes, or a helmet may result in serious injury or death. Always wear protective gear, clothing, and helmet when riding the scooter. Ensure protective gear does not interfere with steering, or braking.

Always wear:

- Colors that are easily seen and, if possible, reflective clothing.
- Clothing appropriate for the weather conditions.
- Always wear shoes.
- Use of protective gear such as pads for the knees and elbows is highly recommended for children.
- A properly fitted, ASTM or SNELL approved, helmet shall be worn at all times by riders of the scooter.



Do not wear:

- Loose clothing parts, strings, or jewelry that may become entangled with moving parts on the scooter or interfere with handling of the scooter
- Shoes with untied shoe laces




Many states have passed helmet laws regarding children. Make sure you know your states helmet laws. It is your job to enforce these rules with your children. Even if your state does not have a children’s helmet law, it is recommended that everyone wear a helmet.

3. Recommended Rider


Product Name	Age	Max Weight
Force 100	5+	176 lb
Force 150/200	8+	220 lb

4. Assembly

Parts Reference




- A** Quick-Release Lever
- B** Stem
- C** Hex Key
- D** Deck
- E** Folding Lever



Force 100

- E** Handlebars & Side Clamp
- F** Top Cap Screw



Force 150/200


- E** Handlebars & Top Plate
- F** Stem Bolts (2)

Illustrations may vary from actual product.

STEP 1


Unfold the scooter.

- 1 Press the folding lever down and raise the stem to the vertical position.



- 2 Push the folding lever forward to lock the stem in place.

Note: The lever will click when it's fully engaged.




STEP 2


Install the handlebars.

Force 100:


- 1 Align the pin with the notch at the top of the stem, then slide the handlebars on.



- 2 Tighten the side clamp bolt securely.




- 3 Screw on the top cap and tighten.




Force 150/200:

- 1** Align the top plate with the stem. Insert both bolts and partially tighten them.



- 2** Alternately tighten both bolts to secure the handlebars.




STEP 3

Adjust the handlebar height.


1

Open the quick-release lever.




2

Push the button and slide the handlebars to the desired height. The button must snap into one of the holes.



3

Close the quick-release lever snugly. Adjust tension by turning the nut on the opposite side of the lever as needed.



STEP 4

Get ready to ride.

***1. CHECK ALL PARTS
ARE SECURE.***

***2. ENSURE BRAKES
WORK PROPERLY.***

***3. WEAR YOUR
HELMET!***

5. Use

1. Grip the handlebars firmly with both hands.
2. With one foot firmly on the scooter, begin to slowly push the scooter forward with the opposite foot.
3. Brake by pressing down on the rear wheel stop until contact is made with the wheel.
4. If the scooter model comes with a kickstand, use it to hold the scooter in an upright position when not in use.

6. Maintenance



WARNING: Proper maintenance is critical to the performance and safe operation of the scooter. Always inspect the scooter and conduct necessary maintenance before each use of the scooter. Failure to conduct maintenance on the scooter may result in malfunction of a critical part or serious injury or death.

This section presents important information on maintenance and will assist you in determining the proper course of action to take if you do have a problem with the operation of the scooter. If you have questions regarding maintenance please contact our Consumer Care team or see a qualified mechanic. Do not call the store where the scooter was purchased.

The following procedures will help you maintain your scooter for years of enjoyable riding.

- For painted frames, dust the surface and remove any loose dirt with a dry cloth. To clean, wipe with a damp cloth soaked in a mild detergent solution.
- Clear any debris between the wheels and frame
- Store your scooter indoors when not in use. Prolonged exposure to UV rays, rain, and elements may damage the components.
- Riding on the beach or in coastal areas exposes your scooter to salt which is very corrosive. Clean your scooter frequently.
- If paint has become scratched or chipped to the metal, use touch up paint to prevent rust. Clear nail polish can also be used as a preventative measure.
- Check that the wheels are securely fastened and axle nuts are tight.

JOIN THE **BORN IN DIRT**TM **CREW**

1

Register Your Ride

Let's make it official. We'll handle the boring stuff so you can stay out riding.

2

Leave a Review

Tell us how your ride treats you.
Your feedback helps other riders.

3

Follow the Action

Keep up with us on social and
tag your shots with #Mongoose.

@mongoosebikes



**START
HERE**



mongoose

**Need a hand?
We got you:**

help.mongoose.com

Text: 1-866-450-0414

Call: 1-800-626-2811

Monday-Friday, 8 AM-6 PM Central Time

