

Item # : BR2DCLNS

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 26/07/2019 (E)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .














- VII. Power tools should not be used to assemble this product.





















- VIII. Drill may be needed for securing product to wall.


Parts List



Hardware List

A		Ø8x30mm	Wooden dowel	18 pcs
B		Ø6x35mm	Cam bolt	20 pcs
C		Ø15x11mm	Cam lock	12 pcs
D		Ø30mm	Sticker	20 pcs
E		Ø6x50mm	Bolt	4 pcs
F		Ø6x12mm	Bolt	16 pcs
G			Plastic wedge	6 pcs
H		M 4	Hex key	1 pc
J			Handle	4 pcs
K		Ø4x12mm	Handle Bolt	4 pcs
L		Ø3x17mm	Screw	4 pcs
M			Plastic wedge	4 pcs
N		Ø4x35mm	Screw	10 pcs
P		Ø3x12mm	Screw	20 pcs
Q			Connecting iron sheet	2 pcs
R		Ø15x9mm	Cam lock	8 pcs
S			Glue tube	1 pc
T			Drawer slider	2 sets


* Note: This piece comes preassembled for shipping purposes and must be disassembled to complete the desk assembly.



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Secure cam bolt (B) to part (1) with Philips head screwdriver .

Step 2




Insert wooden dowel (A) into parts (3,6,16) as per diagram.

Step 3




Insert wooden dowel (A) into parts (4,5), then secure cam bolt (B) to parts (4,5) with Philips head screwdriver .

Step 4



Pull out the slider bracket from the slider arm as per diagram.



Step 5



Using screw (P) attach drawer slider arm (T) to parts (4,5) with Philips head screwdriver as per diagram.



Step 6

2 x





Using screw (P) attach drawer slider bracket (T) to parts (13,14) with Philips head screwdriver as per diagram.

Step 7





Using cam lock(C) secure parts (3,6) to part (5) with Philips head screwdriver as per diagram.

Step 8




Using cam lock(C) secure parts (3,6) to part (4) with Philips head screwdriver as per diagram.

Step 9




Using cam lock(C) secure part (1) to parts (4,5) with Philips head screwdriver as per diagram.

Step 10




Put part (10) into parts (3,4,5) as per diagram.

Step 11




Using bolt (E) attach part (2) into parts (4,5) with hex key (H) as per diagram.

Step 12




Using bolt (F) attach plastic wedge (G) into parts (7,8,9), then using bolt (F) attach connecting iron sheet (Q) to parts (8,9) with hex key (H) as per diagram.

Step 13





Using bolt (F) attach connecting iron sheet (Q) to part (7) with hex key (H) as per diagram.

Step 14






Using bolt (F) attach connecting iron sheet (Q) to part (7) with hex key (H) as per diagram.

Step 15




Using bolt (F) attach plastic wedge on parts (7,8,9) to part (2) with hex key (H) as per diagram.

Step 16



Using screw (L) secure plastic wedge (M) to part (10) with Philips head screwdriver as per diagram.


Step 17



2 x


Secure cam bolt(B) to part (11), using screw (K) attach handle (J) into parts (11) with Philips head screwdriver as per diagram.

Step 18



Using screw (N) attach parts (13,14) to part (12) with Philips head screwdriver as per diagram.


Step 19



2 x



Put part (15) into parts (12,13,14) as per diagram.

Step 20




Using screw (N) secure part (12) into part (16) with Philips head screwdriver as per diagram.

Step 21




Using cam lock(R) secure part (11) to parts (13,14) ,then using cam lock(C) secure part (11) to part (16) with Philips head screwdriver as per diagram.

Step 22



Place sticker (D) cover the holes as per diagram .

Step 23



Put slider bracket into slider arm as per diagram .

Step 24



Final Assembly