




# Installation Instructions for Element Series Passage Leversets


## Step 1.

- Fold template where indicated.
- Position template on door edge at desired latch height.
- Firmly hold template and mark latch height and handle fixing holes at required backset (refer template).
- Measure door thickness and mark centre.
- Drill 25mm (1") latch hole.
- Drill 54mm (2 1/8") hole through door face at required backset as marked on template.




## Step 2.

- Mark and chisel door edge for latch face plate to a recess of 2mm or until flush with door. Use latch face plate as a template.
- Pre-drill wood screws holes with suitable drill size



## Step 3.


- Insert latch support into hole as shown (suitable and required for 54mm hole prep).



**Note:** If retrofitting to an existing hole prep less than 54mm, the latch support will not be required.

## Step 4.

- Insert latch (through latch support if used) with wood screws provided.



**NOTE:** Carefully follow these instructions when installing. Screws to be tightened to a recommended 2.5Nm torque.



Mark centre-line of latch hole

Mark centre-line of latch hole

FOLD HERE

Fit here on door edge

Fit here on door edge

54mm (2 1/8") hole – refer Step 1.

BACKSET 60mm (2 3/8")

Suits doors 32mm (1 1/4") to 45mm (1 3/4") thick.

**Installation template for passage applications**



**ALLEGION**

schlage.co.nz

PDSC0025R1







## Installation Instructions for Element Series Passage Leversets

### Step 5.

#### Install lever assemblies to door

- Insert square drive spindle (1) through latch in door.
- Identify which side of the door each lever assembly will need to be located in order to allow both levers to move in a downward motion once installed.
- Remove rosette covers (2) from both lever assemblies.
- Place one lever assembly (3) onto the square drive spindle.
- Place other lever assembly (4) into position, locating it onto the other end of spindle.
- Fasten both lever assemblies together with screws provided (5):  
Use long screws for thick doors and short screws for thin doors.  
Each under-rose features a countersunk hole and a threaded hole. Install one screw from either side, through the countersunk hole, through the latch and into the threaded hole of the opposite under-rose. Then tighten the screw head on each side.
- Tighten the grub screws (6) at base of levers on both sides with the hexagonal key (7) provided.
- Re-apply rosette covers (2) to both under-roses by pushing the covers over the rubber rings until flush with door.



Suits doors 32mm (1 1/4") to 45mm (1 3/4") thick.

**Installation template for passage applications**



**ALLEGION**

schlage.co.nz

PDSC0025R1

