


## ELECTRONIC DOOR CHIME **EDC - EDC1120WH1**



The patent-pending Electronic Door Chime (EDC) is a doorbell chime kit that can be installed in new construction homes or retrofitted in existing homes. It uniquely features a door chime that *fits in most non-metallic single-gang junction boxes* and *combines both line and low voltage in one unit*. The EDC features selectable chimes and volumes, a *paintable faceplate* for a seamless look, and a lighted doorbell button to make your doorbell easily visible at night.



x1

Lighted Button  
Included



Virtually **eliminate warranty callbacks** and **save installation time and cost** with the **NICOR EDC** Electronic Door Chime.



- Paintable Faceplate**  
Paintable to Match Any Scheme
- Low Voltage**  
Doorbell Wiring
- Voltage Divider**  
Combines Line- & Low-Voltage
- Simple Wiring**  
Line & Neutral AC Input
- Compact Size**  
Fits most Single-Gang Boxes



5 Selectable Chimes




Bronze and Nickel  
Stucco Button Accessories

## INSTALLATION INSTRUCTIONS

For detailed instructions, see instruction sheet inside box.

1. Carefully unpack fixture. Installation location must have access to both line voltage wiring for the EDC and low voltage wiring for the button.
2. Snap off excess material from the voltage divider to an appropriate length.
3. Press divider into the Chime, making sure it is fully engaged.
4. Connect line voltage wiring. Note: Cap off ground wire in junction box.



5. Connect low voltage doorbell wires. A second button (sold separately) can be installed for control from a second door.
6. Install into junction box with the provided screws. Ensure wiring is not pinched or interfering with the divider.
7. Attach doorbell button to chime wiring using screw terminals and mount doorbell button.
8. Apply power. The button should illuminate. Test functionality of the chime.